

Instructions de montage

Assembly instruction



Model No. TABLE-BSK-BALDER-160

Parts list

- ① X22 
- ② X34 
- ③ X4 
- ④ X1 
- ⑤ X1 
- ⑥ X4 




- A X1 
- B X1 
- C X1 
- D X1 
- I X1 
- J X1 
- K X1 



- G X2 
- H X2 
- E X2 
- M X1 
- N X1 
- O X1 


Step 1




Please pay attention to the direction of the parts, the hole is below.
 S'il vous plaît, faites attention à la direction des pièces, les trous se trouvent ci-dessous.




Step 2



Step 5



Step 3



Step 6



Step 4



Step 7

